

## System 3 Draining Instructions.

Use these if the alarm system has been spiked.

1. Remove lid from main alarm unit.
2. Remove internal battery link from PCB (arrowed)
3. Remove alarm inline fuse
4. Unplug PCB from alarm loom

**Leave these parts out over a period of at least 6 hours, to allow the system to drain completely.**

With the bikes battery still in place and fully charged.

1. Plug PCB onto loom and reinstall
2. Replace In-Line fuse.
3. The alarm will sound for a period of approx. 30 seconds.
4. Allow the system to reset itself.
5. Replace internal battery link onto PCB.
6. Make sure all connections are complete and replace lid
7. Disarm system as normal (this may take up to 3 presses as system realigns itself)

